

Thank you for choosing Powerpods Basis. Please read this manual carefully to get the best performance and long life from your earbuds.

User Manual

Key Features

- Up to 25 Hours Battery Backup (with charging case)
- Voice Changer Function (3 Voice Effects)
- Clear Sound & Deep Bass
- Touch / Button Controls
- Fast & Stable Wireless Connection

Voice Changer Function

- Powerpods Basis comes with 3 built-in voice changer modes for fun and interactive use.
- How to Activate Voice Changer:
- Press the Volume Up (+) button three times to activate Voice Changer Mode 1.
- Press the Volume Up (+) button three times again to switch to Voice Changer Mode 2.
- Press the Volume Up (+) button three times again to switch to Voice Changer Mode 3.
- Repeat the same action to cycle through all voice modes.